

# Manual of Motion Controller Operation

## **1. Installation of the hardware**

- (1) Insert the PCI motion control card in the PC.
- (2) Connect the motion controller to the PCI card via the cable.
- (3) Connect the stages to the motion controller via the DB-9 cables.

## **2. Installation of the software**

- (1) Double-click the installation file and install the driver and demo program in the PC.
- (2) After the installation of the software, run the demo program and setup the parameters according to your special requirement then operate the stages via the PC software.

## **3. Making your own software**

- (1) Program your own software via VB or VC.
- (2) Refer to the Manual of Function Library, which explains the Function Library in detail.